



## Manual Calibration of Z offset Option 1




1. Move Cam 300mm along XAxis G0X300 and target to 0,0,0
2. Record angle q and calculate r & s
3. Calculate c
4. Manually jog Tilt Axis until target is centered. U = degrees jogged.
5. Calculate L
6. Repeat from -300, and also do for Y -300/+300. Take average of all 4 estimates.

## Manual Calibration of Z offset Option 2



1. Move Cam 300mm along XAxis G0X300
2. Move to Z to zero (though any z could be used)
3. Target camera to put cam at parallel to "floor" (Tilt = 0?)
4. Manually jog Tilt Axis until target is centered.  $\alpha$  = degrees jogged.
5. Calculate  $a$ .
  1. Option 1:
    1.  $c=b/\cos(\alpha)$
    2.  $a=\sqrt{c^2-b^2}$
  2. Option 2:
    1.  $a = \tan(\alpha) * b$
6.  $J$  = thickness of rail. True Zero being center of rail.
7.  $Z$  Offset =  $a - z + (.5 * J)$
8. Repeat from -300, and also do for Y -300/+300. Take average of all 4 estimates.



● [0,0,0]

When targeting 0,0,0,  
P should be 0, if Z =0.  
After Homing, Camera  
may not be at true Zero  
and therefore we need  
apply an appropriate  
correction.